

- 1/ Open Bonnet.
- 2/ Remove the original plastic bumper cover. (Note: to do this it is necessary to remove the fog lamps. The fog lamp covers are removed by twisting AntiClockwise).
- 3/ Remove original steel bumper reinforcement bar.
- 4/ Place the supplied steel mounting brackets on the bumper reinforcement bar studs and refit the original bumper reinforcement bar, using the original nuts and tighten.
- 5/ Carefully refit the original plastic bumper cover, **it is best to place masking tape on bumper cover where the steel brackets protrude thru, to avoid scratching the bumper cover.**
- 6/ Fit Alloy bar to the vehicle and loosely bolt in place using the supplied 4 x M12 bolts, lock nuts & washers.
- 7/ Align as required and tighten bolts.

### Components

- 1 - Aluminium Bar
- 2 - Steel mounting brackets
- 1 - Fitting instruction
- 4 - M12 Bolts
- 4 - M12 Nyloc Nuts
- 4 - M12 Washers