

- 1/ Remove the vehicles original plastic bumper cover.
 - 2/ Remove original alloy bumper reinforcement bar.
 - 3/ Attach the supplied steel mounting brackets to the back of the original alloy bumper reinforcement bar via the supplied M8 s/s cap screws and tighten.
 - 4/ Using the original bolts, bolt the original alloy bumper reinforcement bar back onto the vehicle and tighten.
- Note: on some models the foam bumper padding and/or plastic bumper cover may require slight trimming to clear nudge bar brackets.
- 5/ Carefully refit the original plastic bumper cover, **it is best to place masking tape on bumper cover where the steel brackets protrude thru, to avoid scratching the bumper cover.**
 - 6/ Fit Alloy Nudge bar to the vehicle and loosely bolt in place using the supplied M12 bolts, lock nuts & washers.
 - 7/ Align as required and tighten bolts.

Components

- 1 - Aluminium Nudge Bar
- 2 - Powder Coated
Steel mounting brackets
- 1 - Fitting instruction
- 4 - M12 Bolts
- 2 - M12 Nyloc Nuts
- 4 - M12 Washers
- 2 - M8 s/s Cap screws