

## **NBSP-055**

- 1/ Remove the vehicles original plastic bumper cover.
- 2/ Remove original alloy bumper reinforcement bar.
- 3/ Place supplied Nudge bar steel brackets between original alloy bumper reinforcement bar and chassis and using the original bolts, bolt alloy bumper reinforcement bar back into place, and tighten bolts.  
Note: on some models the foam bumper padding and/or plastic bumper cover may require slight trimming to clear nudge bar brackets.
- 4/ Carefully refit the original plastic bumper cover, **it is best to place masking tape on bumper cover where the steel brackets protrude thru, to avoid scratching the bumper cover.**
- 5/ Fit Alloy Nudge bar to the vehicle and loosely bolt in place using the supplied M12 bolts, lock nuts & washers.
- 6/ Align as required and tighten bolts.

### **Components**

- 1 - Aluminium Nudge Bar
- 2 - Powder Coated  
Steel mounting brackets
- 1 - Fitting instruction
- 4 - M12 Bolts
- 2 - M12 Nyloc Nuts
- 4 - M12 Washers