

1. Remove original plastic sump guard.
2. Using supplied M8×30mm bolts (2), sump guard washers (4) and nyloc nuts (2), loosely bolt supplied 10mm thick aluminium extension plate (through larger diameter holes in extension plate) to rear mounting holes in SubaXtreme sump guard.
Note: 10mm plate can go on top or bottom of sump guard.
3. Using two supplied M8×30mm bolts (2) and sump guard washers (2), loosely bolt front of sump guard to vehicle, placing the supplied round plastic spacers on each front mounting point between sump guard and the vehicle body.

NOTE: Some models have a metal spacer bracket fitted between the front mounting points of the plastic sump guard and body, if so remove these brackets.
4. Using two supplied M8×30mm bolts (2) and sump guard washers (2), loosely bolt the rear of the sump guard extension plate to the vehicle.
5. Position sump guard to obtain best fit and tighten all bolts.

Components

- 1 – Aluminium sump guard
- 2 – Round HDPE plastic (white) spacers
- 1 – 10mm aluminium extension plate
- 6 – M8×30mm bolts
- 2 – M8 nyloc nuts
- 8 – M8 sump guard washers
- 1 – Fitting instruction