



Manufacturers of Subaru Accessories

SG-055

Sump guard Fitting Instructions -Forester 06

1. Remove original plastic sump guard.
2. Place sump guard in position. Using 2 supplied M8 x 25mm bolts & washers loosely bolt front of sump guard to previously used holes.
3. Using 2 supplied M8 x 25mm bolts & washers loosely bolt rear of guard to old mount holes.
4. Position sumpguard for best fit, checking for clearance with exhaust pipe and bracket near front bolts. Tighten all bolts.

Components

- 1- Aluminium sump guard
- 4- M8 x 25mm bolts
- 4- Flat washers
- 1- Fitting instructions