

Diff guard Fitting Instructions



DG-001

1. Loosen the 2 rear mounting bolts from the back of the diff to subframe (loosen to give 10-12mm gap between the diff mounting bush, and the flange nut)
2. Remove the 2 nuts from the crossmember holding the front of the diff to the chassis.
3. Using a crowbar (pinchbar) or similar, lever the diff forward enough to slide the diff guard up between the back of the diff and the front of the subframe bushes.
4. Refit the 2 nuts which you removed at step 2 to the front bolts, (you will need a tube socket as there is not a lot of room in the mounting cups)
5. Retighen all bolts to manufacturer's specifications using a torque wrench (recomended torque 28Nm, (21 lb ft)).

Components list

- 1 - Aluminium diff guard
- 1 - Fitting instructions

Tools required for fitment

- Ratchet
- 17mm socket (tube socket prefered)
- Crow bar (prybar)

