



Sumpguard Fitting Instructions
Outback '10-'20 (Diesel Only)

SG-046/047/048D

Component list:

1- Aluminium sumpguard	3- Aluminium 15mm spacers
3- M8x45mm Bolts	1- Fitting instructions
3- M8x40mm OD SG Washers	

1. Remove original plastic sumpguard.
2. Locate M8 holes in front subframe (870mm apart).
3. Bolt sumpguard in position using 3 supplied M8x45mm bolts with washers and spacers between sumpguard and subframe.
4. Align sumpguard for best fit giving clearance around exhaust and other components.
5. Looking from rear of sumpguard towards front of vehicle please ensure there is clearance between the sumpguard and the DPF [diesel particulate filter] should be aprox 10mm gap.
6. Tighten all 3 bolts to 24Nm.
7. Enjoy your motoring. Please recheck bolts after 1,000 Kms.