



**Fitting instructions
for Subaru Forester
09-12
SG-057**

Components list:

1 x Aluminium sump guard	4 x M8 x 35mm Bolts
2 x 15mm Round aluminium spacer	4 x 3mm x 40mm Washers
1 Small black steel mounting bracket	1 x Fitting instructions

1. Where possible, safely lift the front of the vehicle and using a clip removal tool, remove original plastic sump guard.
2. From the rear engine cross member cover plate, remove the front two bolts and loosen the rear two bolts.
3. Fit the black steel bracket between the front two bolt holes of the engine cross member cover plate and the engine cross member. Refit the front bolts and tighten ALL bolts, (10 for 2010 model) sandwiching the mounting bracket in place-see last photo. (2010 model has larger plate)
4. Hold the sump guard in position. Using two supplied M8x35mm bolts/washers and placing 15mm aluminium spacers on each of the front mounting bolts (between sump guard and body) loosely attach to car.
5. Using two M8x35mm bolts and washers, loosely attach the rear of the sump guard to the steel mounting bracket.
6. Position sump guard to obtain best fit, checking for clearance between exhaust and sump guard then tighten all bolts.