



Fitting instructions for SJ
Forester Sump guard
SG-058

Components list:

1 Aluminium sumpguard	1 Steel mounting bracket
2 Round 15mm aluminium spacers	4 M8x35 bolts
4 M8x40mm OD SG Washers	1 Fitting instructions

1. Remove original plastic sumpguard.
2. Identify the black coverplate shown in the left hand photo below and remove two bolts.
3. Fit the supplied steel mounting bracket between the chassis and the previously mentioned coverplate. Refit both bolts and tighten.
4. Hold the sumpguard in position. Using two supplied M8 bolts, washers and placing aluminium spacers on each of the front mounting bolts (between sumpguard and body) loosely attach to car.
5. Using two M8 bolts and two large washers, loosely attach the rear of the sumpguard to the steel mounting bracket.
6. Position sumpguard to obtain best fit, checking for clearance between exhaust and sumpguard then tighten all bolts.

