



**Fitting instructions for
Subaxtreme Strut tower brace
– All models**

Components list:

1 x Subaxtreme Strut Brace

Tools required:

Ratchet and a set of sockets, some models may vary in thread size.

Fitting instructions:

1. Remove the two inner bolts on the top of each strut top tower as indicated in the photo below.
2. Place the strut tower brace over the protruding threads on each strut top tower.
3. Replace the bolts that we removed and retighten. (**Torque setting 96 Nm or 71 ft lbs**)



Two inner strut tower bolts.



Two inner strut tower bolts.

Please note, this is a generic photo of a strut top tower your specific model may look different.