



Fitting instructions for
Subaru Outback BR
Transmission guard TG-046

Components list:

1 x Transmission guard	1 x M8 x 45mm Bolt
1 x Mounting bracket	3 x M8 x 40 mm washers
2 x M8 x 30mm Bolts	

Fitting instructions.

1. Safely Elevate front of vehicle using stands, a hoist or ramps.
2. Undo the two outer factory bolts from the vehicle's rear transmission mounting bracket and fit the provided transmission guard mounting bracket using the two factory bolts you removed. (This bracket is handed, fit the narrow side to the drivers side,
3. If you have one of our Subaxtreme sump guards on your car, please remove the rear M8 x 35mm bolts and washers- leaving the front two bolts in place. Line the transmission guard up with the front mounting hole and loosely fit the M8 x 45mm bolt and washer supplied in the kit.
4. If you're fitting this transmission guard without a sumpguard, loosely fit the M8 x 45mm bolt and washer through the single front hole into the rear engine crossmember.
5. Line the rear transmission guard holes up with the mounting bracket and loosely fit the two M8 x 30mm bolts and washers into the mounting bracket nutserts.
6. Once the transmission guard is lined up properly, tighten all three bolts up securely.

(Recomended torque 28Nm, (21 lb ft).