



Fitting instructions for TG-058 & TG-058-XT

Components list:

2 X M8x35mm Bolts	4 x M8x40mm washers
2 X 26mm Aluminium spacers	2 x M8x45mm Bolts
1 x Transmission bracket	

1. If possible, safely lift the vehicle and remove the plastic factory sump guard or your Subxtreme sump guard.
2. Locate and Remove factory bolts from exhaust cradle bracket, making sure to keep these bolts for later.
3. Using the factory bolts kept from previous step, install the transmission guard bracket using the same bolt holes.
4. Hold transmission guard in place and using the 35mm bolts secure the transmission guard to the bracket, leaving the bolts loose to allow for adjustment.
5. At front of transmission guard Place the two aluminium spacers between the transmission guard and the vehicle. hold the guard in place and using the M8x45mm bolts provided secure the front of transmission guard and tighten all bolts
6. **If you have a Subxtreme sump guard this will overlap slightly with the transmission guard, both will use the same M8x45mm bolts to secure the guards.**
Make sure to place Subxtreme sump guard on top of Subxtreme transmission guard

