



Fitting Instructions for TG-057 4EAT

| Component's list | Equipment needed |
|---------------------------|---|
| 2x M10x 55mm Bolts | 12mm spanner or socket with ratchet to suit |
| 2x M10 Washers | 14mm spanner or socket with ratchet to suit |
| 2x 40mm Aluminium spacers | 16mm spanner or socket with ratchet to suit |
| | Jack stand or hoist to raise the underbody of the car for safe installation |

Photo 1

Step 1.

Remove two existing outer front bolts from the subframe making sure to keep these two bolts for later, as seen in highlighted area of photo 1.

Step 2

Remove two bolts from the inner side of passenger side cross member as seen in highlighted area on photo 2, these bolts do not need to be kept.



Step 3

Once bolts have been removed, offer up trans guard in correct position as seen in photo 2 and fit the two bolts to the front of the guard that were kept from earlier making sure to fit loosely at first.



Photo 2

Step 4

Fit M10 x 55 bolts with spacers and washers to the rear cross member as seen in photo 3.

Step 5

Check for adjustments needed

Step 6

Tighten all bolts

Photo 3

